



INSTALLATION INSTRUCTION

TWO HANDLES WALL-MOUNT SHOWER SET

雙把手淋浴組安裝說明

NOTE: Disassemble the **Handles & Face Plates** from the **Mixer Valve Body** First. Using the **Sleeves** provided to protect the external threads while installation if required.

注意從包裝盒中取出：安裝前，先將把手與面板從本體鬆開。如須使用隨附塑膠套筒保護陶瓷中心栓及螺牙，必須在安裝程序前先套好。

1. Reserved the Thickness of Wall (Fig#1)

須預留牆壁的厚度。(如圖示1)

Pay attention to minimum 2" (5cm) and maximum 3" (7.6cm) dimensions for mounting information as shown. (Fig#1)

牆壁內本體與牆面的距離須保持在最小2"(5cm)到最大3"(7.6cm)之間，此為安裝時的必要條件。

2. Install Mixer and Showerhead Lines: Connect hot and cold water supply lines, then install 1/2" shower line and 1/2" pipe elbow to **Mixer Valve Body**. (Fig#2)

安裝牆壁內本體和淋浴供水管線，連接冷熱水供水管線。(通常熱水是安置在左邊水道) 裝置淋浴供水管線，將所有接頭塗上管牙膠或包覆止洩帶，再組裝1/2"水管下端到牆壁內本體上，同時並組裝1/2"彎頭到1/2"水管的上端。

3. Install Showerhead: Place **Showerhead Flange** over the thread-end of **Showerhead**，apply pipe compound to **Showerhead** and 1/2" elbow, install nipple between **Showerhead** and elbow, adjust the nipple length if necessary. Tighten **Showerhead** by hand. (Fig#3)

安裝淋浴噴頭：將法蘭蓋從淋浴噴頭的接牆壁端套入，再將其接牆牙端與牆內1/2"彎頭內牙及中間必要接合的接頭1/2"牙，塗上管牙膠或包覆止洩帶，接好鎖緊，即可完成淋浴噴頭安裝。

4. Assemble Handle Bonnets and Handles: Attach **Handle Bonnets** onto **Handle Shank** and cut overlong **Valve Stems** to certain length (1/4"~5/8" or 6mm~16mm) as shown for fix handles. (Fig#4 & 5). Press **Handles** over the **Valve Stems** to proper position and tighten Handle Setscrews. When installing with Lever Handles，ensure that handles are properly aligned when valves are in closed. (Fig#6)

組合把手蓋和把手：鎖緊把手蓋到牆內本體的牙管上，並依需要可切除把手蓋過長的閥心軸，以便組裝把手。將把手裝入閥心軸到適當位置，再用隨附的六角板鎖緊把手內的埋頭螺絲，安裝一字把手時，請先關閉冷熱水開關，再將冷熱水把手依水平方向裝置。

WARNING: The two lids which sealed up the **Mixer Valve Body** can't be removed.

注意：十字把手上端的白色陶瓷蓋片出廠時已被固定，請勿嘗試從該處拆除。